






Wiring instructions

- NO: Normally Open Contact.
- COM: Common Contact.
- NC: Normally Close Contact.

Driving Mode		Electric lock		Jumper port	Connections
Active	Passive	No electricity when open	When the power to open		
√		√			 Electric-lock: No electricity when open the door
√			√		 Electric-lock: When the power to open the door
	√	√			 Electric-lock: No electricity when open the door
	√		√		 Electric-lock: When the power to open the door
	√	√			 Electric-lock: No electricity when open the door